

Greer T55/55 Components by Honeywell

<u>Part Number</u>	<u>Description</u>	<u>TAT</u>
1-300-363-03	Ignition Unit, Exciter Type - Test	40
1-300-363-04	Ignition Unit, Exciter Type - Test	40
2-010-050-08	Tailpipe Assembly - UFR	60
2-060-190-10	Output Shaft Support Housing Assembly - UFR	60
2-060-590-09	Head Assembly, Electric Torquemeter- Ovhl	60
2-060-590-09	Head Assembly, Electric Torquemeter - Test	30
2-061-093-09	Bearing Support, Front, No. 3 - UFR	60
2-061-280-07	Inlet Housing - UFR	60
2-070-000-12	Accessory Drive Carrier Assembly - UFR	45
2-070-010-07	Accessory Drive Gear Carrier - UFR	60
2-080-350-12	Cover and Support Assembly - UFR	60
2-080-370-10	Case Assembly, Gearbox - UFR	60
2-080-450-06	Accessory Gearbox Assembly - UFR	60
2-080-450-14	Accessory Gearbox Assembly - UFR	60
2-100-040-55	Stage 4 Stator - UFR	45
2-100-050-36	Stator Vane Stage 5 - UFR	45
2-100-060-45	Stator Vane Stage 6 - UFR	45
2-100-230-24	Stator Vane Stage 7 - UFR	45
2-101-238-09	Compressor Shaft - UFR	45
2-101-550-40	Housing and Vane Assembly - Base Repair (assumes all parts are repairable)	60
2-101-580-19	Stage 3 Stator - UFR	45
2-101-600-57	Compressor Assembly - Base Repair(rejected parts not included)	60
2-101-600-57	Compressor Assembly - UFR (does not include life limited components)	60
2-101-600-57	Compressor Assy - Check and Balance	30
2-101-640-09	Housing No.2 Bearing - UFR	60
2-101-650-08	Housing No.2 Bearing Retainer - UFR	60
2-101-790-39	Stator Vane Stage 1 - UFR	45
2-103-048-08	Impeller Shroud - UFR	60
2-103-090-14	Stage 2 Stator - UFR	45
2-103-240-02	Compressor Housing Assembly - UFR	60
2-110-070-31	Air Diffuser Assembly - Minor Repair (No Vane Replacement)	60
2-110-070-31	Air Diffuser Assembly - With Vane Replacement	60
2-111-100-22	Diffuser Curl - Additional for Outer Flange Replacement	60
2-111-100-22	Diffuser Curl - Cracks and Thermal Barrier Coating	60
2-121-100-60	Stage 2 Turbine Nozzle - UFR	60
2-121-100-79	Stage 2 Turbine Nozzle - UFR	60
2-121-430-20	Stage 1 Turbine Nozzle - UFR	60
2-121-430-25	Stage 1 Turbine Nozzle - Base Repair(rejected parts not included)	60
2-121-470-49	GP Cylinder - UFR	60
2-121-480-32	1st & 2nd Stage GP Rotor Assembly - Base Repair(rejected parts not included)	60
2-131-090-38	Combustion Housing - UFR	60
2-131-110-76	Combustion Liner - UFR	60

Greer T55/55 Components by Honeywell

<u>Part Number</u>	<u>Description</u>	<u>TAT</u>
2-131-120-03	Turning Vane Set - UFR	45
2-131-140-09	Fireshield Section, Inner - UFR	45
2-131-340-01	Fireshield Assembly, Rear- UFR	45
2-141-050-08	Output Shaft Assembly - UFR	60
2-141-073-18	Housing, Turbine, Support - UFR	60
2-141-120-57	Stage 3 Turbine Nozzle - Minor repair	60
2-141-120-57	Stage 3 Turbine Nozzle- Ovhl	60
2-141-170-22	4th Turbine Rotor Assembly- Base Repair(rejected parts not included)	60
2-141-338-06	Support, Third Turbine Nozzle - UFR	45
2-141-350-10	Third Turbine Rotor and Shaft Assembly - Base Repair	60
2-141-350-10	Third Turbine Rotor & Shaft Assembly- Base Repair & End Cone Replacement	90
2-141-360-07	Third Turbine Disc and Shaft - Base Repair & End Cone Replacement	90
2-141-430-18	Stage 4 Turbine Nozzle- Minor repair	60
2-141-430-18	Stage 4 Turbine Nozzle- Ovhl	60
2-160-010-21	Starter Drive Assembly - UFR	45
2-160-010-26	Starter Drive Assembly - UFR	45
2-160-020-15	Starter Housing Assembly - UFR	45
2-160-350-36	Interstage Air-Bleed Actuator - UFR	45
2-160-750-04	Oil Cooler - UFR	60
2-160-790-04	Fuel Boost Pump - Ovhl	60
2-160-790-04	Fuel Boost Pump - Test	45
2-160-790-04	Fuel Boost Pump (Overhaul / Mod from -04 or -12 to -13)	60
2-160-790-13	Fuel Boost Pump - Ovhl	60
2-160-950-37	Left hand (No.1) Fuel Manifold - UFR	45
2-160-950-38	Right Hand (No. 2) Fuel Manifold - UFR	45
2-161-630-03	Main Fuel Filter Assembly - Test	60
2-170-420-01	Inline Fuel Filter and Element Assembly - Test	60
2-170-560-06	DECU - Functional Test	45
2-170-560-09	DECU - Functional Test	45
2-170-560-09	DECU -06 to -09 exchange	45
2-170-580-02	Hydromechanical Assembly - Functional Test	30
2-170-580-02	Hydromechanical Assembly - Minor Repair	60
2-170-580-02	Hydromechanical Assembly - Major Repair	60
2-170-580-02	Hydromechanical Assembly - Overhaul	60
2-170-700-02	ECU - Functional Test	45
2-170-700-02	ECU - Minor Repair	45
2-170-700-02	ECU - Major Repair	45
2-200-071-67	Torque Kit - Base Repair	60
2-300-216-03	Nozzle, Starting, Combustion Chamber - UFR	45
2-300-272-03	Ignition Coil and Cable Assembly - Test	45
2-300-272-04	Ignition Coil and Cable Assembly - Test	45
2-300-387-05	Carbon Seal - UFR	45

Greer T55/55 Components by Honeywell

<u>Part Number</u>	<u>Description</u>	<u>TAT</u>
2-300-387-06	Carbon Seal - UFR	45
2-300-832-03	Buss Bar Assembly L.H. - UFR	30
2-300-833-03	Buss Bar Assembly R.H. - UFR	30
2-300-908-01	Fuel Flow Divider - UFR	60
2-300-932-01	Oil Pump - Ovhl	60
2-300-932-01	Oil Pump - Test	30
2-300-974-01	Chip Detector - UFR	60
2-302-036-02	Oil Pump - UFR	60
2-303-797-01	Valve, Pressurizing - UFR	45
2-303-907-02	Junction Box, Electric Torquemeter - UFR	60
2-310-033-01	Solenoid Valve - UFR	45
2-310-036-02	Valve, Solenoid, Starting Fuel - UFR	45
2-310-039-01	Valve, Programming - UFR	45
2-310-081-02	Harness - Yellow	60
2-310-143-01	Harness - Green	45
2-310-148-01	Harness - Blue	45
2-310-156-01	Harness - Reversionary - UFR	45
2-310-157-01	Harness- Primary - UFR	45
2-310-158-01	Harness- T4.5 - UFR	45
2-310-159-01	Harness- Accessory - UFR	45
2-310-192-01	RDPS - Test / No Fault	30
2-310-192-01	RDPS - Minor Repair	45
2-310-192-01	RDPS - Major Repair	60
2-310-192-02	RDPS - Test / No Fault	30
2-310-192-02	RDPS - Minor Repair	45
2-310-192-02	RDPS - Major Repair	60